

CHRISTIE LITES

Indu Electric 36 & 72 Channel 220V HD distro phasing

On each Socapex output, phase is:

Circuit 1 X

Circuit 2 Y

Circuit 3 Z

Circuit 4 X

Circuit 5 Y

Circuit 6 Z