

CHRISTIE LITES

Skjonberg 30 and 60 Channel 208V HD distro phasing

On each Socapex output, phase is:

Circuit 1 XY

Circuit 2 XY

Circuit 3 ZX

Circuit 4 ZX

Circuit 5 YZ

Circuit 6 YZ